



Leggett & Platt® Flooring Products

Scotchgard™ Cushion

Installation Guidelines

1. Inspect the floor to ensure it's clean and free of debris.
2. If desired, apply a non-flammable adhesive in small amounts to the corners of the room. This will help hold the cushion in place during installation. Staples may also be used around the perimeter of the room. However, stapling along seams is not recommended.

Scotchgard carpet cushion features a VaporFLO moisture barrier that should face up against the carpet.

3. Install the cushion perpendicular to carpet seams. Cut the cushion to fit the room with as few seams as possible.
4. Use a flexible, moisture resistant-type tape at the cushion seams and to cover any tears, punctures, or staples. **The use of masking or other paper-based tapes is not recommended.**
5. Once Scotchgard carpet cushion is installed and seams are mended, you are free to install carpet.

For more detailed instructions on installing carpet cushion, visit Carpet-Rug.org or reference the CRI Carpet Installation Standard.

Guía de Instalación

1. Inspeccione el piso para asegurarse de que esté limpio y libre de desechos.
2. Si desea, aplique un adhesivo no inflamable en pequeñas cantidades en las esquinas de la habitación. Esto ayudará a mantener la almohadilla en su lugar durante la instalación. También pueden usarse grapas a lo largo del perímetro de la habitación. Sin embargo, no se recomienda grapar a lo largo de las costuras.

El bajo alfombras Scotchgard cuenta con una barrera contra la humedad VaporFLO que debe quedar hacia arriba contra la alfombra.

3. Instale la almohadilla en forma perpendicular a las costuras de la alfombra. Corte la almohadilla para que se ajuste a la habitación con el menor número de costuras posible.
4. Utilice una cinta flexible de tipo resistente a la humedad en las uniones de las almohadillas y para cubrir desgarros, perforaciones o grapas. **No se recomienda, el uso de cinta de enmascarar ni ningún otro tipo de cinta a base de papel.**
5. Una vez que el bajo alfombras Scotchgard está instalado y las costuras se reparan, puede instalar la alfombra.

Para obtener instrucciones más detalladas sobre la instalación del bajo alfombra, visite Carpet-Rug.org o consulte el Estándar de instalación de alfombra (CRI por sus siglas en inglés, Carpet Installation Standard).

Leggett & Platt
FLOORING PRODUCTS